




YoLink Hub

YS1603-UC, YS1603-EC



Installation & User Guide

Revision Jul. 30, 2026

Contents

A . Welcome!	01
B . Before You Begin	02
C . In the Box	05
D . Get to Know Your YoLink Hub	06
E . Install the App	08

F . Add Your Hub to the App	09
G . Installation	11
H . Connections & Power Up	13
I . WiFi Considerations	15
J . Mobile Device Settings	17

K . WiFi Set-Up	19
L . App Functions: Device Screen	24
M . App Functions: Device Details Screen	25
N . App Functions: Alarm Strategy	26
O . Adding Devices	27

P . Factory Reset	29
Q . Firmware Update	30
R . Specifications	29
S . Troubleshooting	31
T . Warnings	37

U . Warranty	38
V . FCC Statement	39
W . CE Mark Warning	41
X . IC Caution	42
Y . Contact Us	43



Welcome!

Thank you for purchasing YoLink products! We appreciate you trusting YoLink for your smart home & automation needs. Your 100% satisfaction is our goal. If you experience any problems with your installation, with our products or if you have any questions that this manual does not answer, please contact us right away. See the Contact Us section for more info.

Thank you!

YoLink Customer Support

User Guide Conventions

The following icons are used in this guide to convey specific types of information:



Very important information
(can save you time!)



Good to know info but may not
apply to you

B Before You Begin

Visit our Smart YoLink Hub support page on our website, for the latest installation guides, additional resources, information and videos by visiting:

<https://www.yosmart.com/support/YS1603-UC>

Or by scanning the QR code:



Download the most current version of the user guide by scanning the QR code:



B Before You Begin, Continued

YoLink Hubs are the gateway to the internet for your YoLink devices. As opposed to many smart home systems, the individual devices are not on your network or WiFi and are not directly connected to the internet. Instead, your devices communicate with the Hub, which connects to the internet, the cloud server and the app.

Your Hub requires a full-time internet connection. This can be provided by your WiFi and/or a direct connection to your internet/network equipment (also known as an Ethernet connection). If using a WiFi connection, please note, like most IoT and home automation devices, your Hub connects only to the 2.4 GHz WiFi band. Nearly all residential WiFi routers have a 5 and a 2.4 GHz band. But your router may or may not display SSIDs for both bands or they may both have the same name. If you know which SSID is your 2.4 GHz band, this is the one your Hub will connect to. With some exceptions, your router and the Hub will connect automatically via 2.4 GHz. Some routers may attempt to connect your Hub to 5 GHz. Additional setup support may be needed, for example, changing your router settings. Refer to the WiFi Considerations section for more information.

B Before You Begin, Continued



“5 GHz” should not be confused with “5G” cell phone service

You can have multiple hubs, including a combination of this YoLink Hub and other YoLink hubs. While the YoLink wireless network has up to a ¼ mile open-air range, additional hubs may be required in large buildings, such as high-rises, and/or to support thousands of devices.




Multi-step authentication WiFi networks, like hotel or airport WiFi, are not supported!




In the Box




YoLink Hub




Quick Start Guide



USB Cable



Ethernet Cable ("Patch Cord")




AC/DC Power Supply Adapter



Get to Know Your YoLink Hub

Please take a moment to familiarize yourself with your new YoLink Hub, in particular the LED behaviors and SET button functions.



LED Behaviors



Green PWR LED Flashing
Power On



Blue Internet LED On Solid
Connected To Internet



Blue Internet LED Flashing Quickly
Wifi Settings Change




Red FEAT LED Flashing Slowly
Device Updating



Red FEAT LED Flashing Quickly
Restoring To Factory Defaults

D

Get to Know Your YoLink Hub, Continued



Ethernet Jack LED Behaviors



Fast Blinking Yellow
Normal Data Transmission



Green Light On
Port Is Connected To Router Or Switch



Slow Blinking Yellow
No Response From The Router



Either Light Off
Something Is Wrong

(Disregard LEDs If Port Is Not Being Used)



Install the App

If you are new to YoLink, please install the app on your phone or tablet, if you have not already. Otherwise, please proceed to the next section.

Scan the appropriate QR code below or find the “YoLink app” on the appropriate app store.



Apple phone/tablet
iOS 9.0 or higher



Android phone/tablet
6.0 or higher

Open the app and tap **Sign up for an account**. You will be required to provide a username and a password. Follow the instructions, to set up a new account. Allow notifications, when prompted.


You will immediately receive a welcome email from no-reply@yosmart.com with some helpful information. Please mark the yosmart.com domain as safe, to ensure you receive important messages in the future.

Log in to the app using your new username and password.


The app opens to the **Favorite** screen. This is where your favorite devices and scenes will be shown. You can organize your devices by room, in the **Rooms** screen, later.

F Add Your Hub to the App

1. Tap **Add Device** (if shown) or tap the scanner icon:



2. Approve access to your phone's camera, if requested. A viewfinder will be shown on the app.




3. Hold the phone over the QR code so that the code appears in the viewfinder. If successful, the **Add Device** screen will be displayed.

F

Add Your Hub to the App, Continued

4. You can change the device name and assign it to a room later. Tap **Bind device**.

5. If successful, the screen will appear as shown. Tap **Done**.



If you experience difficulties scanning in a new device, ensure the code is not dirty or smudged, and that the camera has adequate lighting. If you are still unable to scan a device, please make a note of the serial number for our customer support staff. This is the number right below the QR code, a long number preceded by "S/N"

Installation

You can, and you may find it more convenient to, set-up your Hub at a desk or table before placing it or installing it where it will be permanently located, but direct connection to your internet/network hardware (router, switch, satellite, etc.) via Ethernet is required for “plug, plug & play” set-up. You will connect the Hub to your internet/network equipment either using the included Ethernet patch cord, or another Ethernet cord.

And it is also worth considering that for larger homes and buildings, and/or if you will have devices outside of your home, it's possible you may need to relocate the Hub to an optimal location, in order to cover your entire home, building or property. And should one Hub not be sufficient, you can add as many hubs as you want, later, to extended the coverage of the YoLink wireless network.

The Hub is USB-powered and it will require a dedicated AC outlet for the included USB power adapter, or it can be plugged directly into a compatible USB outlet.

The Hub does not have an internal battery, it must be constantly plugged into a suitable source of power, as noted above.



Installation, Continued


You may consider powering your internet/network equipment and the Hub from a UPS back-up power supply, with the purpose of maintaining full functionality in the event of a power outage and loss of internet connection. And, consider the use of our Control-D2D device-to-device pairing feature, which is outlined in the product user guides. Paired devices can work even with the loss of power and internet (battery-powered or backed-up devices, only).

Your hub is intended to be installed indoors, and kept clean and dry.

Do not place your Hub near sources of heat, like a space heater, as well as intense direct sunlight, either of which can damage the Hub.


Avoid placing your Hub inside, on or near metal, or sources of radio or electromagnetic energy or interference. Avoid placing your Hub under or on top of your WiFi router, satellites or any such RF signals transmission sources.

H Connections & Power-Up




1. As shown, power up the Hub by connecting one end the USB cable (A) to the power jack (B) on the Hub, and the other end to the power adapter (C), plugged into an outlet

2. The **green power indicator** should flash:





3. It is recommended that you connect your Hub to the network/internet even if WiFi-Only is your intended format. Using the supplied Ethernet patch cord (D), connect one end (E) to the Hub, and the other end (F) to an open port on your router or switch. The blue Internet indicator should turn on:





Connections & Power-Up, Continued

4. In the app, the Hub is now shown to be Online, with the Ethernet icon green as shown:



5. If you plan to connect your Hub to the internet via the Ethernet cable, only, and your Hub is online, proceed to section L, to complete the setup of your Hub.



If your Hub is **NOT** Online after this step, please double-check your cable connections. Check LED indicators on the Ethernet jack on your Hub (refer to section D). There should be similar LED activity on your router or switch (refer to your router/switch documentation)



WiFi Considerations

Your Hub connects to the cloud via an Ethernet and/or WiFi connection. If an Ethernet connection is available, we recommend using it, and this is the “Plug, Plug & Play” method that will result in the easiest and fastest setup of your Hub. There are additional considerations, specific to using a WiFi connection with your Hub:

- Changes to your internet provider, internet equipment may require updating the WiFi-related settings in the YoLink app again.

Changing your WiFi passwords or SSID name will require updating the WiFi-related

- settings in the YoLink app again.

A WiFi connection, if optional, may not be ideal for you if:

- Your WiFi is not dependable or stable.
- You are not the owner/administrator of the network/WiFi.
- You’ve forgotten or do not have the WiFi password.
- Your WiFi has a second verification process or additional security.
- You’d rather not share your WiFi credentials with additional apps.



WiFi Considerations, Continued



If you have a mesh and/or WiFi 6 type network, like a Google Nest, TP-Link Mesh, or Eero, you will most likely need to disable the 5GHz WiFi band while connecting your Hub. Helpful information can be found on the Hub's product support page, or contact our customer support department.



Mobile Device Settings

1. iOS phones only: if prompted, enable Local Network Access. (Search “iOS location services” for more information)

2. If prompted, grant access to your location. Tap **Allow Once**. This is required for the next steps.

To check or edit Location Services on your phone:

iOS:



Go to Settings, tap Privacy, tap Location Services
Ensure **Location Services** is on/enabled.

Scroll down to and tap the **YoLink** app
Select **While Using the App**

Enable **Precise Location**

Android:



Go to **Settings**, tap **Location**.

Ensure Location is On.

Tap **App Permissions**. Scroll down to and
tap the YoLink app, then set permission to
Allowed Only While in Use





Mobile Device Settings, Continued

Ensure you are logged into your WiFi:

- 1.** In your phone, open WiFi settings (Settings, WiFi).
- 2.** Identify your 2.4 GHz network, if possible. If there is only one SSID (network ID) you recognize, you will use that one.
- 3.** Select the appropriate network and log-in, if needed.
- 4.** If your SSID is hidden, you must manually log into it on your phone, by selecting "Other..." in Other Networks or Choose a Network.

K WiFi Set-Up

1. If you are able to, but have not already provided your Hub with an ethernet connection, as explained in the Connections & Power-Up section, do so at this time.
2. In the app, from the Rooms or Favorites screen, tap the YoLink Hub icon.
3. Refer to WiFi icon, it should read “Not Connected” – tap this icon.





WiFi Set-Up, Continued

4. Please carefully review the instructions on the **Setup Wi-Fi** screen. After pressing the SET button on the Hub, you will then log into the Hub's hotspot on your phone. This will need to be done with no delays between steps, otherwise the Hub will exit hotspot mode (in 5 minutes).
5. As directed in the app, press the Hub's SET button for 5 seconds or until the WiFi LED flashes rapidly.
6. Without closing the YoLink app, go to your phone's WiFi settings and log into the Hub's WiFi hotspot. It is identified as YS_1603#####. Disregard any messages that may appear, warning you the hotspot does not have an internet connection. If requested, approve "Once" or "This Time Only"





If you get an error message "failed to obtain Wi-Fi" grant access to your phone's location data, per the previous section.



WiFi Set-Up, Continued

7. If you see a “connect to device timeout” message, tap **Close**.

8. Promptly return to the YoLink app. Check the “Please confirm the above operation” checkbox. Tap **Continue**. The Enter WiFi Password screen appears as shown.





WiFi Set-Up, Continued

9. In the **Choose a WiFi box**, select your 2.4 GHz SSID from the drop-down menu list, or type in your SSID, if needed.
10. Enter your WiFi password, then tap **Continue**.
11. After a short process, the **Set up WiFi successfully** message is displayed, as shown. Tap **Done**.
12. If your Hub was not already connected to internet, the Hub's blue internet status LED should now be on solid, indicating the Hub is connected to the internet.
13. Your Hub may appear offline in the app, if it was not already connected to the internet via the Ethernet cable. Tap the refresh icon or swipe down on the screen, to refresh the app.
14. In the app, confirm the WiFi icon is green (indicating a WiFi connection), with your SSID name shown below it.
15. If you are not leaving your Hub connected to Ethernet, you may remove the Ethernet patch cord at this time. Verify the Hub's WiFi LED indicator remains a solid blue, and in the app, the Hub online.
16. If you are moving your Hub to its permanent location, you can do so at this time. Verify the Hub comes online automatically shortly after being powered back up.

K WiFi Set-Up, Continued




If you experience difficulties connecting the Hub to your WiFi, try temporarily disabling or turning off your 5 GHz band. Check for this option in your router's app, or by connecting to your router via a browser interface (refer to your router documentation, as needed). For example, for the Eero router, in the app, go to Settings, Troubleshooting, "My device won't connect", then tap "Temporarily pause 5 GHz".



App Functions: Device Screen

In the app, tap on your YoLink Hub icon. Your main screen should be similar to the one shown below.





App Functions: Device Details Screen

Tap the three dots (in the upper right corner) to open the **Details** screen. Your screen should be similar to the one shown below.

The screenshot shows the 'Details' screen for a YoLink Hub. The screen is divided into several sections with various settings and information. Annotations point to specific elements:

- Device Type**: Points to 'YoLink Hub' under the 'Type' field.
- Device Name (Tap to Edit)**: Points to 'YoLink Hub' under the 'Name' field.
- Room (Tap to Edit)**: Points to '1603/4' under the 'Room' field.
- Favorite (Red if Favorite, Tap to Edit)**: Points to a heart icon under the 'Favorite' section.
- Alarm strategy for this device**: Points to 'Disabled' under the 'Alarm Strategy' section.
- Device online/offline state**: Points to 'Offline' under the 'State' field.
- Your WiFi network name**: Points to 'PDCN' under the 'Wi-Fi' field.
- Current Network**: Points to 'Ethernet' under the 'Current Network' field.
- IP Address info**: Points to the 'IP Address' field in the network details section.
- Model Number**: Points to 'YS1603-UC' under the 'Model' field.
- Device EUI Unique Identifier Number**: Points to 'd88b4c1603035feb' under the 'Device EUI' field.
- Device Serial Number**: Points to 'FEAF988468' and a QR code under the 'SN' field.
- Firmware Revision (Refer to page 30)**: Points to '0362' under the 'Firmware' field.
- Remove Device From Current Account**: Points to a red 'Delete' button at the bottom.

The screen layout includes a top bar with a back arrow, 'Details' title, and a help icon. The main content area has sections for basic info (Type, Name, Room), preferences (Favorite), alarm settings (Alarm Strategy), status (State), network settings (Wi-Fi, Current Network, IP Address, Gateway, Network Mask), and device identification (Model, Device EUI, SN, Firmware). A red 'Delete' button is at the bottom.



App Functions: Alarm Strategy (Hub Offline Alarm)

To configure offline notifications for your hub, follow these steps:

1. Navigate to the 'Device Details' screen.
2. Select 'View your alarm strategies' to access alarm strategy settings.
3. Tap the '+' icon located in the lower right corner to create a new alarm strategy specifically for your hub.
4. In the new strategy, ensure that your hub is selected (indicated by a checkmark).
5. Finally, customize the notification settings as per your requirements.

← Alarm Strategy ⓘ

Name Hub >

Related Devices 1 >

🔔 Enable Device Alarm ☒

Do Not Disturb

🔕 Do Not Disturb ☐

📱 Send App Notification All ▾
iOS Notification Settings ...
Will send App Notification to All Home Members when device alerts

✉ Send Email All ▾
Will send Email to All Home Members when device alerts

💬 Send SMS None ▾
Will not send SMS when device alerts

🔔 Trigger Action None >
Have not set any action

Save

0 Adding Devices

Your Hub will be awfully lonely without some devices, like smart locks, light switches, water leak sensors or sirens to interact with. Now is the time to add your devices). You already know how to do this, because you added your Hub to the app; it is the same process of scanning the QR code that is on each device. Look again at part F for a refresher.

1. For each new device, refer to the instructions in the quick start guide* packaged with each product. It directs you to download the full Installation & User Guide, using the QR code in the "QSG". Refer to the full manual, and when directed, scan the device's QR code to add it to your system.



The quick start guide, or QSG, is a small and basic set of instructions that are packaged with each product. The QSG is NOT intended to guide you through the entire installation and user guide process, but it is only meant to be an overview. The full manual is too large to be included, plus, while the QSGs may be printed in advance, the manuals are always kept current with the latest updates to your products and app. Please always download the full Installation Manual & User Guide, to ensure the smoothest installation.



Adding Devices, Continued

2. When directed in the manual, turn on your device (typically by pressing the SET button).
3. Always confirm your device is online in the app before proceeding to the next device. Refer to Figure 1, for an example of of online and offline devices.




Figure 1



Factory Reset

Factory reset will erase device settings and restore it to factory default settings. Doing a factory reset will not remove the device from your account and it will not harm the device, or lose any data or require you to redo your automations, etc.

Instructions:

Hold the SET button down for 20-30 seconds, until the LED blinks. Then, release the button. (Holding the button down longer than 30 seconds will abort the factory reset operation)

Factory reset will be complete when the LED stops blinking.



Only deleting a device from the app will remove it from your account. Factory reset will not delete the device from the app.



Firmware Update

Your YoLink products are constantly being improved, with new features added. It is periodically necessary to make changes to your device's firmware. For optimal performance of your system, and to give you access to all available features for your devices, these firmware updates should be installed when they become available.

In the Detail screen of each device, at the bottom, you will see the Firmware section, as shown in the image below. A firmware update is available for your device if it says "#### ready now"

Tap in this area to start the update.

The device will update automatically, indicating progress by percentage-complete. You may use your device during the update, as the update is performed "in the background". The LED will slowly blink green during the update, and the update may continue for several minutes beyond the LED turning off.



Specifications

Controller:	Semtech® LoRa® RF Module YL09 microcontroller with 32-Bit RISC processor
-------------	---

Listings:	ETL-Listing Pending
-----------	---------------------

Color:	White
--------	-------

Voltage/Current Draw:	5 Volts DC, 1 Amp
-----------------------	-------------------

Dimensions, Imperial (L x W x D):	3.42 x 3.42 x 1.06 inches
--------------------------------------	------------------------------

Dimensions, Metric (L x W x D):	87 x 87 x 27 mm
------------------------------------	-----------------

Operating Temperature Range:	
---------------------------------	--

Fahrenheit:	-4°F – 104°F
-------------	--------------

Celsius:	-20°C – 50°C
----------	--------------




Specifications, Continued

Operating Humidity
Range:


<95% Non-Condensing

Application
Environments:


Indoor, Only



FRONT



SIDE



TOP

Hub(Ethernet) is offline:

Possible Solution

- 1.** Check the LED behavior on the hub. If the LED blinks green, blue, and red alternately, the hub is in ATE mode. Repower the hub without pressing and holding the SET button during the process.
- 2.** If the green LED is dimly blinking, try using another USB adapter and USB cable. Do not plug the USB cable into a USB extension cable, as it may reduce the power supply, causing the hub to malfunction.
- 3.** If the LED blinks green only, check the Ethernet jack's LED lights. The yellow LED should blink, and the green LED should remain on.



If the Ethernet LEDs do not work:

1. Try using a different Ethernet cable (RJ45).
2. If the Ethernet LEDs work properly, try another router port.
3. If the issue persists, restart your router.
4. If the issue still persists, whitelist the MAC address of the hub on your router's configuration page.
5. If none of the above steps resolve the problem, please contact YoLink Customer Support (see the contact info on the last page of this guide).



Hub(WiFi) is offline :

Possible Solution:

- 1.** Check the LED behavior on the hub. If the LED blinks green, blue, and red alternately, the hub is in ATE mode. Repower the hub without pressing and holding the SET button during the process.
- 2.** If the green LED is dimly blinking, try using another USB adapter and USB cable. Do not plug the USB cable into a USB extension cable, as it may reduce the power supply, causing the hub to malfunction.
- 3.** If the LED blinks green only, follow these instructions based on your hub's firmware version (you can view the firmware version in the Device Details screen):

For firmware 032X: Temporarily connect the hub via Ethernet, then go to the YoLink app > tap to select your hub > tap the Wi-Fi icon in the upper right corner, input your SSID and password, then unplug the Ethernet cable. If you're using a 2.4GHz Wi-Fi band, make sure your phone is connected to the 2.4GHz band before entering the password.



Troubleshooting, Continued

For firmware 035X or newer: Use the hotspot configuration method as instructed by the app. If you encounter a "Connect to device timeout" error, tap Close, pull down the notification panel on your phone, and select the notification about no internet access. Tap "Yes" to stay connected to the hotspot and continue. Alternatively, you can temporarily connect the hub via Ethernet and input the SSID and password on the Wi-Fi configuration page in the app.

If you're using a mesh network, search for a solution to temporarily disable the 5GHz band on your router forum or contact YoLink with your router brand and model for assistance. Temporarily disabling 5GHz will not disconnect your other devices.

Please ensure that you follow these troubleshooting steps and instructions for the proper connection of your YoLink Hub to Wi-Fi.

Warnings

- Power the Hub with the provided adapter, only
- The hub is designed and intended for indoor use and is not waterproof. Install indoors, avoiding subjecting the Hub to water or damp conditions
- Do not install the hub inside or near metals, ferromagnetism or any other environment which may interface with the signal
- Do not install the Hub near flames/fire or expose to high temperatures
- Please do not use strong chemicals or cleaning agents to clean the hub. Please use a clean, dry cloth to wipe the hub to avoid dust and other foreign elements entering the Hub and affecting the operation of the Hub

Avoid allowing the hub to be exposed to

- strong impacts or vibration, which may damage the device, causing malfunctions or failure

2 Year Limited Electrical Warranty

YoSmart Inc. warrants to the original user (“customer”) of this product that it will be free from defects in materials and workmanship, under normal use, for 2 year from the date of purchase. This warranty does not apply to devices that have been improperly installed, modified, put to a use other than designed, or subjected to acts of God (such as floods, lightning, earthquakes, etc.). This warranty does not cover neglected or abused products. This warranty is limited to the repair or replacement of the device, only, at YoSmart's sole discretion. YoSmart will NOT be liable for the cost of installing, removing, nor reinstalling this product, nor direct, indirect, or consequential damages to persons or property resulting from the use of this product. This warranty only covers the cost of replacement parts or replacement units, it does not cover shipping & handling fees. The customer must provide proof of purchase, in the form of the original purchase invoice or order number. The purchase must have been made from an authorized seller.

To implement this warranty please contact us by one of the methods listed on the Contact Us page of this user guide.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.



FCC Statement, Continued

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

PRODUCT NAME:
YOLINK HUB

PARTY:
YOSMART, INC.

TELEPHONE:
831-292-4831

MODEL NUMBER:
YS1603-UC

ADDRESS:
25172 ARCTIC OCEAN DRIVE, SUITE 106 LAKE
FOREST, CA 92630 USA

EMAIL:
SERVICE@YOSMART.COM



CE Mark Warning

The host manufacturer has the responsibility that the host device should be compliance with all essential requirement of RER. This restriction will be applied in all member states. The simplified UK declaration of conformity referred shall be provided as follows: Hereby, YoSmart Inc. declare that the radio equipment type YoLink SpeakerHub is in compliance with Directive UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulation (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091).



IC Caution

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

To maintain compliance with RSS-102 RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Pour être conforme aux lignes directrices d'exposition RF RSS-102, cet équipement doit être installé et exploité à une distance minimale de 20cm entre le radiateur et votre corps: n'utilisez que l'antenne fournie.



Contact Us

We are here for you, if you ever need any assistance installing, setting up or using a YoLink app or product!

Need help? For fastest service, please email us 24/7 at service@yosmart.com

Or call us at **831-292-4831** (US phone support hours: **Monday - Friday, 9AM to 5PM** Pacific)

You can also find additional support and ways to contact us at:

www.yosmart.com/support-and-service

Or scan the QR code:



Support Home Page

Finally, if you have any feedback or suggestions for us, please email us at feedback@yosmart.com

Thank you for trusting YoLink!

YoLink Customer Support

YOLINK

25172 Arctic Ocean Drive, Suite 106 Lake Forest, CA 92630
© 2026 YOSMART INC. CALIFORNIA, USA