



Siren Alarm

YS7103-UC

Quick Start Guide

Revision Apr. 04, 2023

Welcome!

Thank you for purchasing YoLink products! We appreciate you trusting YoLink for your smart home & automation needs. Your 100% satisfaction is our goal. If you experience any problems with your installation, with our products or if you have any questions that this manual does not answer, please contact us right away. See the Contact Us section for more info.

Thank you!

Eric Vanzo
Customer Experience Manager

The following icons are used in this guide to convey specific types of information:

- Very important information (can save you time!)
- Good to know info but may not apply to you

Fr Pour des instructions en français, scannez les codes QR dans la section suivante.

Es Para obtener instrucciones en español, escanee los códigos QR en la siguiente sección.

Before You Begin

Please note: this is a quick start guide, intended to get you started on the installation of your Siren Alarm. Download the full Installation & User Guide by scanning this QR code:




You can also find all guides and additional resources, such as videos and troubleshooting instructions, on the Siren Alarm Product Support page by scanning the QR code below or by visiting:

<https://shop.yosmart.com/pages/siren-alarm-product-support>



Your Siren Alarm connects to the internet via a YoLink hub (SpeakerHub or the original YoLink Hub), and it does **not** connect directly to your WiFi or local network. In order for remote access to the device from the app, and for full functionality, a hub is required. This guide assumes the YoLink app has been installed on your smartphone, and a YoLink hub is installed and online (or your location, apartment, condo, etcetera, is already served by a YoLink wireless network).

In the Box



Required Items

The following items will be required:




2 x AA Batteries


The following items may be required:




Drill with Drill Bits



Nail or Screw & Anchor




Phillips Screwdriver




Hammer

Get to Know Your Siren Alarm



Get to Know Your Siren Alarm, Continued



LED Behaviors

- Blinking Red Once, then Green Once
Device Start-Up
- Blinking Red And Green Alternately
Restoring to Factory Defaults
- Blinking Green
Connecting to Cloud
- Slow Blinking Green
Updating
- Fast Blinking Green
Control-D2D Pairing in Progress
- Fast Blinking Red
Control-D2D Unpairing in Progress

Alarm LED

- Blinking Red
Warning
- Fast Blinking Red Every 30 Seconds
Batteries are Low; Please Replace the Batteries

Get to Know Your Siren Alarm, Continued

Alarm Tones

- HI-LO Tone Once
Device Power-up
- HI-LO for 5 Seconds
Sound Level Settings Adjusted
- HI-LO (For Alarm Duration per Settings - Default is 30 Seconds)
Warning

Power Up

1. To power up the Siren Alarm for the first time, first install the batteries. Ensure the switch is in the OFF position. Remove the battery compartment cover by gently prying it open at the notch.

2. Observing the polarity markings on the Siren Alarm, install two new alkaline or lithium, non-rechargeable, batteries.

3. Insert and snap the battery compartment cover back in place.

4. Upon power-up, the siren alarm will briefly activate. You can cover the opening on the front of the Siren Alarm if you wish to muffle this sound and/or you can first slide the switch to the low ("L") position, allow it to activate briefly, then put the switch on the desired high or medium sound level setting.




You can press the SET button to activate the siren if it is off, or to deactivate it is on.

G Install the App

If you are new to YoLink, please install the app on your phone or tablet, if you have not already. Otherwise, please proceed to the next section.

Scan the appropriate QR code below or find the "YoLink app" on the appropriate app store.



Apple phone/tablet iOS 9.0 or higher Android phone/tablet 4.4 or higher

Open the app and tap **Sign up** for an account. You will be required to provide a username and a password. Follow the instructions, to set up a new account. Allow notifications, when prompted.

You will immediately receive a welcome email from no-reply@yosmart.com with some helpful information. Please mark the yosmart.com domain as safe, to ensure you receive important messages in the future.


Log in to the app using your new username and password.

The app opens to the **Favorite** screen. This is where your favorite devices and scenes will be shown. You can organize your devices by room, in the **Rooms** screen, later.

Refer to the full user guide and online support for instructions on the use of the YoLink app.


H Add Your Siren Alarm to the App

1. Tap **Add Device** (if shown) or tap the scanner icon:



H Add Your Siren Alarm to the App, Continued

2. Approve access to your phone's camera, if requested. A viewfinder will be shown on the app.



3. Hold the phone over the QR code so that the code appears in the viewfinder. If successful, the **Add Device** screen will be displayed.

4. Follow the instructions to add your Siren Alarm to the app.

I Installation

Location Considerations:

The Siren Alarm is intended for indoor use. Consider one of our outdoor alarm controllers with siren, for outdoor applications. Place or install your Siren Alarm at an indoor location that is clean and dry, with temperature and humidity conditions within the limits of the product environmental specifications (refer to the product listing or product support page on our website).

The Siren Alarm can be wall-mounted, using the mounting slot on the rear of the device, hanging it from a nail or screw. The Siren Alarm can be placed on any stable level surface, like a shelf or countertop. It is important to securely mount the Siren Alarm and/or protect it from being knocked down—physical damage to the device is not covered by the warranty.

Avoid locating the Siren Alarm near head height or at locations where people may be close nearby when it activates.

I Installation, Continued

Place or install your Siren Alarm at a location with an available AC outlet (for the plug-in power adapter) or with an available USB power outlet. Please note: while the Siren Alarm has batteries, they are only capable of powering it for limited power outages. Your Siren Alarm, on good batteries, should be capable of activating for no less than 5 minutes after being on battery power for 24 hours.


The Siren Alarm is not vandal- or tamper-resistant. If using the Siren Alarm where it may be subjected to tampering, consider mounting it elsewhere. Mounting the Siren Alarm higher on the wall may deter tampering.

When considering where in your home or business to place the Siren Alarm, consider first the requirements and the application. For personal notification, such as for a water leak detection application, locate the Siren Alarm closer to your expected locations in the home or building. For example, if you are concerned about sleeping through a phone push notification or SMS/text message, consider placing the Siren Alarm in or near your bedroom. If you are using the Siren Alarm for security purposes, and want it to scare off an intruder, place it closer to areas where an intrusion is expected, keeping in mind that the intruder should not have easy access to the Siren Alarm (to silence or disable it). If it is required that the siren sound is heard outside of your home or business, consider one of our outdoor alarm controllers and sirens.


We recommend testing the Siren Alarm at the proposed location before installing it. If needed, additional Siren Alarms can be easily added to your system, and they can be configured to activate and deactivate in unison. This may be required for larger homes and businesses, and where ambient sound levels are higher and/or where sound does not carry well between areas.

Install the Siren Alarm:

1. If you are not wall-mounting the Siren Alarm, you can place it where desired, then proceed to the next section, Test Your Siren Alarm.
2. If hanging the Siren Alarm from a nail, hammer the nail into the wall at the desired location, leaving approximately 1/8" or 3 mm space on the end of the nail. Proceed to step 4.
3. If hanging the Siren Alarm from a screw, insert the screw in the wall, at the desired location. If using a wall anchor, install the anchor per the manufacturer's instructions. Insert the screw with a screwdriver, leaving approximately 1/8" or 3 mm space on the end.



4. Hang the Siren Alarm on the nail or screw. Gently tug down on the Siren Alarm, to ensure it is secure.



Test Your Siren Alarm:

You should test the Siren Alarm for basic functionality (e.g. works when you activate it) and to ensure it can be heard remotely, as needed. You can use the SET button to turn the siren sound on and off. Use the Start Alarm button in the app to remotely test the Siren Alarm. If the Siren Alarm is not loud enough throughout all required areas of your home or building, you can change the setting to high ("H"), you can relocate it, or you can add additional Siren Alarms.

Proceed to the full Installation & User Guide or the online product support to complete the set up of your Siren Alarm.

J Contact Us

We are here for you, if you ever need any assistance installing, setting up or using a YoLink app or product!

Need help? For fastest service, please email us 24/7 at service@yosmart.com

Or call us at **831-292-4831** (US phone support hours: **Monday - Friday, 9AM to 5PM** Pacific)

You can also find additional support and ways to contact us at: www.yosmart.com/support-and-service

Or scan the QR code:



Finally, if you have any feedback or suggestions for us, please email us at feedback@yosmart.com

Thank you for trusting YoLink!

Eric Vanzo
Customer Experience Manager

YOLINK

15375 Barranca Parkway
Ste. J-107 | Irvine, California 92618

© 2023 YOSMART, INC IRVINE,
CALIFORNIA